


1.3MP

DIGITAL CAMERA

DSC350

USER'S GUIDE

Please remove the security tag
before inserting the batteries.



CONTENTS

Your package.....	2
Electromagnetic Compatibility Notice.....	2
Trademarks acknowledgement.....	3
Precautions.....	3
Features of the camera.....	4
Batteries used for DSC350 Digital Camera.....	5
Input Compact Flash card.....	6-7
Nomenclature.....	8
Buttons Description.....	9
LCD monitor menu.....	9-10
Remarks.....	10-12
Status LCD Display.....	13
Flash Strobe modes.....	13
Playback on LCD monitor.....	14
Download to computer.....	14
View photos on TV.....	14
CF memory card storage.....	15
Connecting to TV.....	15
Self timer/Digital Zoom / Shot to Shot time/ Rapid fire mode.....	16
Install Arcsoft PhotoImpression Software.....	17-18
Install the camera driver to Win 98/98SE/Me OS.....	19-21
Install the camera driver to Win XP/2000 OS.....	22-25
Use Arcsoft PhotoImpression(Walmart).....	26-29
Open the Manual.pdf file.....	30
Uninstall Arcsoft programs.....	30
Troubleshooting.....	31
Product Specifications.....	32
Software and System Requirements.....	32-33

The DSC 350 Camera kit includes the following items:

DSC350 Camera	1 unit
Software CD ROM	1 piece
USB cable	1 piece
TV (video) cable	1 piece
User's Manual	1 piece
Quick Start Guide	1 piece
Warranty Card	1 piece
Hand Strap	1 piece
Alkaline Batteries (AA)	4 pieces

Default settings -

When you insert the batteries and power-up the camera for the first time, the camera will have the following (default) settings:

Flash strobe: Off
Resolution: FULL*
LCD monitor: Off
Auto Power Off: 1 minute
Sound (beeper): Off
LCD monitor menu language: English
Quick View = Off
White Balance =Auto
Light Frequency = 60Hz
Video: NTSC
Slide show timing: 3-second delay
LCD Brightness/ EV Compensation = 0

Electromagnetic Compatibility Notice

This device complies with Part 15 of FCC regulations. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this camera not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If the unit does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on) the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or any experienced TV/radio technician for help.
- Shielded cables are used with this unit to ensure compliance with the Class B FCC limits.
- *In the event of high electrostatic discharge, the camera may malfunction. To correct this situation, reset the camera by taking out the batteries.*

Trademark acknowledgements:

Vivitar is a trademark of Vivitar Corporation.

The DSC350 TWAIN driver is developed by Conexant Systems, Inc., USA.

Microsoft, Windows 98/Me/2000/XP are the registered trademarks of Microsoft Corporation.

Pentium is a registered trademark of Intel Corporation.

Arcsoft PhotoImpression is licensed to Arcsoft, USA.

All other product names mentioned herein are trademarks or registered trademarks of their respective owners.

Precautions:

Thank you for selecting the Vivitar DSC350 digital camera. Please read these instructions carefully for a thorough understanding of your new camera before taking pictures.

- This camera is not water resistant and should not be used outdoors in snow or rain. If accidentally dropped in water, please quickly pour out the water, and dry in sunlight or using an air-blower.
- Protect your camera from excessive humidity. Excessive humidity may cause moisture to form on the lens and your pictures taken may appear to be blurred.
- Do not expose the camera to sand or dust.
- Do not attempt to disassemble the camera yourself. Always take it to an authorized service facility for repair.
- Remove the batteries if you do not expect to use the camera for 30 days or longer.
- When storing the camera, wrap it in a piece of clean, soft cloth and place it in a cool, dry, dust-free place. Avoid storage in high temperature conditions or in direct sunlight.
- The batteries may explode or cause burns if disassembled, recharged, shorted, exposed to high temperature, or disposed of in fire.
- AA-size alkaline or Ni-MH batteries can be used with this camera. It may damage the camera if you use poor quality batteries.

- Make sure all four batteries are fresh, unused, and fully charged.
- Ensure that battery polarities are correct when placing the batteries in the camera.
- Batteries may feel warm after being used for some time.
- Take care of the lens. Use a soft lens cloth to clean it.
- Do not subject the lens, LCD monitor screen, or viewfinder to sharp or hard objects.
- Condensation is a problem when bringing cold equipment into a warm room. Try to put the camera in a plastic bag so condensation forms on the outside of the bag.
- If the status LCD or the TFT LCD display is damaged, do not touch it.
- Battery low detection:
 - When you see the battery icon blinking, you should replace the batteries with new alkaline batteries or fully charged NiMH batteries.
 - If the batteries are low you cannot use the flash strobe and you should refrain from using the LCD monitor in order to take more pictures.
- Battery life is shorter for low quality alkaline batteries. If you use the LCD monitor and the flash strobe, you should use high quality batteries. High power NiMH rechargeable batteries (1300mAh or higher) are also recommended.

Features of the DSC350 camera:



1. High speed image processing with multiple functions
2. High quality images with SXGA (1280 x 1024) resolution
3. Large aperture glass lens (F2.8)
4. Short shot-to-shot time (~3s for Full * mode)
5. Two resolutions: SXGA - 1024 x 1024 and VGA - 640 x 480
6. Three levels of image of quality at each resolution setting
7. 1.8-inch color LCD monitor (280x220 pixels)
8. Ten function control buttons and 1 mode dial as described in this manual
9. USB port for uploading images to your computer, and PC camera mode
10. Built-in flash strobe (4 modes)
11. Compact Flash memory card (type 1) compatibility (CF card not included)
12. Tripod mounting socket
13. Uses (4) common AA Alkaline batteries
14. Exposure compensation (-1.5 to +1.5 eV)
15. White Balance (Auto and 4 other types)
16. 2X Digital Zoom
17. Quick View feature (to confirm/save the last image, or not)
18. TV video output (PAL or NTSC selectable)
19. Slide show mode - on the LCD monitor or on a TV screen
20. Folder selection (DCF compatibility)
21. Files Protection (Current/All) so images cannot be erased
22. Date/Time setting
23. A choice of seven languages for the LCD monitor menus
23. Auto Power off timing selection (1, 2 or 3 minutes selectable)
24. Ability to erase the current image, or all images

Notice: The DSC 350 has 1MB of internal memory. 500KB is dedicated to camera functionality (the camera operating program). The remaining 500KB of internal memory is available for image storage. This is adequate about six images when the camera is set to " HALF * " (VGA mode - economy quality).

It is strongly recommended that you purchase an optional Compact Flash memory card to use with your camera.






Batteries used for DSC350 Digital Camera -

- Insert four (4) AA alkaline batteries into the battery compartment and close the door. Slide the power switch to the "On" position and hold for at least one second. The camera will turn on and the status LCD (on top of the camera) will display camera data.
- You cannot power up the camera without the batteries.
- In the future, if battery power is disrupted, some of the settings will be automatically reset. For example, the date and time will be lost and must be reset. Each time the batteries are removed the date resets to 01/01/00 12:00.
- As the camera is powered on, the image-LCD monitor is "off" to conserve battery power. Press the "DISP" button to turn on the image LCD if you wish to see a live image, or review stored images.
- The battery icon will blink if battery power is too low. Replace with new alkaline batteries as soon as possible.
- Note: when connected to your computer by USB the camera will not use USB power from the PC, and batteries will be required.








Slide and lift open the battery compartment cover and insert four (4) AA Alkaline batteries with the correct polarities. Then close the battery compartment cover.

Inserting a Compact Flash Card (Optional CF Card - not included in kit):








1. Open the CF card holder cover.
2. Insert the CF card as shown.
3. Lock the ejector. (fit it down)
4. Close the CF card holder cover.
5. Turn the Mode Dial to "Record" mode.
6. Turn on the camera using the sliding power switch.
7. You will see the remaining number of photos (FULL*) that can be taken on the status LCD.

Removing a Compact Flash Card:



1. Turn off the camera
2. Open the CF holder door
3. Unlock the ejector (flip up)
4. Push down on the CF ejector to release the card
5. Remove the CF card by grasping with your fingers
6. Return the ejector to the stowed position
7. Close the CF holder door

Nomenclature:



Description of the Camera Control Buttons:

1. RES: (Resolution) Change from Full* to Half***, Half**, Half*, Full***, Full**.
2. Timer: Turn on/off self-timer (10 second delay)
3. Flash: Toggle between Auto, Red Eye, On (Fill flash), and Off (no flash)
4. Shutter: Press partially to determine exposure settings. Press fully (to bottom of travel) to take an image
5. POWER: Slide to the right momentarily (1 second) to turn on, or turn off the camera
6. MENU: Display or hide the LCD monitor menu
7. UP: Move up in the menu
8. DOWN: Move down in the menu
9. DISP: (Display)
 - In Record mode: Turn on or off the LCD monitor.
 - In Play mode: Toggle between full screen, full screen with image information, and display as 3 x 3 thumbnails
10. ENTER: Confirm the item selection. Digital zoom (in Record mode)

Mode Dial (5 selectable modes):

Rec (Record mode)		For taking pictures
Play (Play mode)		For reviewing stored images
Set (Setup mode)	SET	For displaying the Setup menu
Erase (Erase mode)		For displaying the Erase menu, with a press on the MENU button
PC (PC mode)		For uploading images, and PC camera mode

LCD Monitor Menu:

There are five different menus shown on the LCD monitor.

1. RECORD MENU
2. PLAY MENU
3. SETUP MENU
4. ERASE MENU
5. PC MODE

RECORD MENU

(Turn to REC mode, then press the Menu button)

- LCD Brightness -5 to +5, step 1
- Quick View ON/OFF
- White Balance Auto, Daylight, Incandescent, Fluorescent1, Fluorescent2
- EV Compensate -1.5 to +1.5 eV, step 0.3 eV
- Light Frequency 50Hz or 60Hz

PLAY MENU	(Turn to PLAY mode, then press the Menu button)
• LCD Brightness	-5 to +5, step 1
• Video Mode	NTSC or PAL
• Slideshow	1 to 10 second timing
• Folder	Select another folder
• Protect Images	Protect Current/Unprotect Current, Protect All or Unprotect All

SETUP MENU	(Turn to SETUP mode)
• Date/Time	Set date and time
• Language	Select a camera operating language from your choice of English, French, German, Spanish, Japanese, Portuguese, or Italian
• Sound	Beeper On or Off
• Format Media	Format the CF memory card. Erase the internal memory.
• Auto Power Off	1, 2 or 3 minutes selection

ERASE MENU	(Turn to ERASE mode, then press the Menu button)
------------	--

- Erase Current
- Erase All

PC MODE	(Turn to PC mode, then press the Menu button)
---------	---

- Mass Storage Upload images
- Silent Video PC camera mode

Remarks:

LCD Brightness

You can adjust the brightness of the LCD monitor to suit the lighting conditions. It is not easy to see your images outdoors in sunlight, so you may wish to increase the image-LCD brightness. For indoor viewing, you can use the default value (0).

Quick View

If Quick View is set to "On" and the LCD monitor is set to "Off", you will see a brief display of the images you take, for 3 seconds. While the image is being displayed - you may elect to delete the image, by pressing the 'ENTER' button before the LCD monitor is turned off. If you do not delete the image, it will be saved to memory.

White Balance

A digital camera is different from the human eye. Your eyes can see a white subject regardless of the lighting conditions. A digital camera includes internal firmware (a computer program) that is designed to automatically correct your images in order to reproduce a true color image. However, this may fail in some special cases. You may assist your camera to correctly adjust the colors by changing from Auto White Balance to Daylight, Incandescent, Fluorescent1 (Daylight fluorescent lamps) or Fluorescent2 (warm white fluorescent lamps).

Note however, that the ability to specify lighting conditions is disabled if you use the flash. Therefore you must to disable the flash if you want a particular effect.

EV Compensation

If the background of your scene is very bright compared to your subject (eg. Sunny day, snow mountain), the exposure may be too low for the intended subject. You may wish to increase the exposure by increasing the exposure value - eV (from +0.3 to +1.5). Likewise, if the background is too dark compared to the subject (eg. black wall), you may to decrease the eV (from -0.3 to -1.5)

Note: + 1eV = the exposure is doubled. -1eV = the exposure is halved

Light Frequency

If you use the camera as a web cam, you need to select a light frequency equivalent to your local AC-power frequency. The US and Canada is 60Hz, whereas Europe is 50Hz.

Video Mode

Select the TV system (either NTSC or PAL) to match your TV system. NTSC is mostly for USA and Japan, whereas PAL is common in Europe.

Slideshow

You can change the display-interval timing from 1 to 10 second for playing slide shows.

The time is preset to 3 seconds. When viewing a slide show you may stop the slide show at any point by pressing the ENTER button.

Folders

Initially a folder named "100cnxnt" will be created on your CF memory card. Images will be stored in this folder. You may create new folders (using a CF card reader) before using the CF card. This can help you organize your images in a preferred logical structure and order. You may create folder names from "101cnxnt" to "999cnxnt". Place a camera image file in the desired folder. Next, insert the CF card into the camera and turn the power on. The camera will show this new folder when you select the Folder item in the Play Menu. If you turn the Mode Dial to Record mode, all the new images will be saved into this new folder (eg. 101cnxnt).

Protect Files (images)

This feature is used to protect important images from being inadvertently erased. You may protect the current image, or all images. There is an icon (resembling a lock) in the upper left corner of the image display (when image information is shown - press DISP button).

Note however, protected images will still be erased if you format the CF card. You will hear a warning beep if you attempt to erase a protected image.

Date/Time

You may enter the date (month/day/year) and time (hour/minute). Your images will be stored with date and time when they were taken. Use the Up/Down button to increase/decrease the value. Press ENTER to confirm and go to the next entry. The menu will return to the Setup menu when the minute value is set.

Language

Any one of seven common languages can be selected for the LCD monitor menus: English, French, German, Spanish, Japanese, Portuguese and Italian. English is preset.

Format Media

It takes about 2 seconds to format a CF memory card (~1s to erase the internal memory). Make sure you have uploaded your important images to your PC before formatting your CF card.

Note: You may select "Yes" or "No" to "Reset Image No.?" when you use the Format Media feature. If you select "Yes", the next image taken after formatting will be numbered 1. If you select "No", the next photo taken after formatting will follow the numbering sequence before the media is formatted. For example, if 3 images were taken before formatting, after choosing "No" to "Reset Image No.?", the next photo taken after formatting will be numbered 4.

PC Mode

- **Mass Storage:** Turn the Mode Dial to PC mode. Connect the camera to your PC with the USB cord. Slide the Power switch to the on position to power on the camera. The 'PC' icon will be seen on the status LCD.

From the Windows Desktop, click on 'My Computer'. You will see a removable disk icon representing the memory in your camera. All the images stored on your CF memory card (or the 500KB internal memory) can be uploaded to the PC hard drive by copying files from this removable disk.

- **Silent Video:** If you select this item (press Menu, Down, ENTER), the USB camera mode is set. You may now use your camera for video conferencing (web cam mode).

Status LCD display



Icon descriptions

1. Battery icon: 2 Levels of battery power indication
2. 4-digit 7-segment display:
 - In Record mode - shows the total number of images left
 - In Play mode - shows the number of the last image (eg. 0008)
3. Flash strobe icon: Flash Off (☺), Flash On (⚡), Auto Flash (no icon),
4. Red Eye Reduction: Pre-flash is set to avoid red eye. (👁)
5. Timer: 10-second delay after the Shutter button is triggered. Timer icon (⌚)
6. HALFULL : FULL = SXGA 1280x1024, HALF = VGA 640x480
7. *** : Image quality setting. *** High, ** Normal, * Economy
8. Rapid Fire mode icon: (📷)

Messages Displayed on the 7-segment display:

- BUSY - Image data is being processed to be saved as JPG file to memory
- PC - Mode dial is turned to PC mode.

Front face LED indication:

Off	Self-timer is not used
Blinking	Self-timer has been initiated

Flash Strobe Modes:

The flash is preset to "Auto Flash" when the batteries are inserted

Auto: the flash fires according to the light condition.

On: the flash is forced to fire. This is useful for backlit scenes. This is known as a "fill-flash"

Off: the flash is suppressed and will not fire. This is used for indoor lighting or for taking objects at a distance too far for the flash to have an effect. The camera will utilize its white-balance corrective algorithms to get natural colors

Red Eye: this will help to ensure the subject's eyes appear natural (not red) when photographing in low lighting conditions. The flash will fire a pre-flash just before the picture is taken and then fire again to take the actual picture.

Playback on LCD monitor


- Turn Mode Dial to "Play" mode  the last image will be displayed.
- Press the "UP" or "DOWN" buttons to review your images
- Press the "MENU" button to set the following:
 - LCD Brightness, Video Mode, Slide Show, Folder, Protect Files
 - Video Mode (select NTSC/PAL TV system)
 - Slide Show time interval (from 1 to 10 seconds)
 - Folder (select the folder you want to review)
 - Protect files (to protect the images from being erased)
- Press "DISP" once to display image information
- Press "DISP" twice to display 9 image thumbnails together



Downloading Images to your Computer

* Make sure you have installed the camera driver and taken some images. For details of driver installation, please refer to the camera driver installation section of this Manual.


1. Turn on the camera
2. Turn the mode dial to "PC" mode
3. Connect the camera to your computer using the USB cable
4. Open Windows Explorer
5. Look for the "Removable Disk" folder



6. Expand this icon until you see the folder "100cnxnt" under "Dcim".
7. Click on "100cnxnt" folder and you will see your image files
8. Copy them to your hard drive or other storage location

Viewing your images on a TV

1. Connect the camera to the TV with the provided TV cable
2. Power on the camera
3. Turn the Mode Dial to "Play" mode 
4. The last image file is shown on the TV screen
5. Press the "UP" or "DOWN" button to view other images



CF memory Card Storage:

If you have an optional CF memory card, you may store images as shown in the following table:

	16MB	32MB	64MB
Resolution & Quality -			
Full ***	15	30	60
Full **	30	60	120
Full * or Half ***	60	120	240
Half **	120	240	480
Half *	240	480	960

FULL = SXGA 1280x1024,

HALF = VGA 640x480.

Quality: *** (High), ** (Normal), * (Economy)


Note: The above table is the approximate number of images that may be stored. The actual number of image you can store varies according to the image environment (visual complexity).

- Only CF type 1 memory cards are suitable for the DSC350 camera.
- Using quality CF memory cards eg. San Disk, Lexar, Kodak is recommended. Compatibility with other poor quality CF memory cards is NOT guaranteed.
- If you insert the CF card while the camera is powered on, you must power off and on again to get the frame number estimation to match the CF card memory size
- Do not change the directory (folder) names or file names from your PC. If you do so, the camera may open the image files
- Images are stored in the folder Dcim\100Cnxnt of the CF card. You may save the images to PC directly by using a CF card reader
- If you copy image files from other sources to your CF card, they cannot be viewed by the camera

Connecting to a TV:

When connected to a TV you can view all features normally presented on the image LCD

- Connect the TV cable as shown. You can see live video if the camera is set to "Record" mode
- You can review images if the camera is set to "Play" mode. This is ideal for reviewing images with a group of people in front of a large TV screen.



Self-Timer

Press the Timer button to turn on the self-timer. The self-timer icon is shown on the status LCD display. Press the shutter fully down to trigger the self-timer. You will hear beep after the 7th second. The camera will take an image after the 10th second. The front LED will blink during the 10-second period.

Digital Zoom

In "Record Mode", press the "DISP" button to turn on the image display and press "ENTER" button to use the 2X Zoom mode. "2 x D Zoom" will be displayed in the bottom left-hand corner of the display. The central portion of the image is enlarged (zoomed) by a factor of two. Press the Shutter button to take an image. Press the "ENTER" button again or switch off the power, and the 2 X Zoom function will be cancelled.

Note: When the 2 X Zoom is activated, the image resolution will automatically be set to VGA, i.e. HALF*.

This simulates the effect of using a 2X zoom lens. It is best to review the images on image display.



Image on TV/TFT



Digital Zoom Image on TV/TFT

Shot-to-Shot time

This is the processing time for the camera before it is ready for next shot. The following table presents shot-to-shot time for resolution and quality combinations.

Quality mode	Processing time
FULL ***	~6s
FULL **	~4s
FULL * / HALF ***	~3s
HALF ** / HALF *	~2s

Rapid-Fire (Burst) Mode


In the Record mode, press the "RES" button until the icon "  " is displayed. By pressing and holding the shutter button, you may take continuous images. The camera will continue to take images until the available memory is used up.

Because of the time required to re-charge the strobe after each photo, it is recommended that the strobe flash be de-activated when using the rapid-fire mode.


Half  : VGA 640 X 480

Full  : SXGA 1280 X 1024

Installing the Arcsoft PhotoImpression Application Software




Put the CD-ROM into your CD-ROM drive
It will automatically start and run
Click 'Next'.
Click 'Yes' to accept the license agreement
Click 'Next' to install Arcsoft Photo Impression.



Click 'Yes' to accept the license agreement.



Click 'Next'.
Click 'Next' if you will not update the Program Folder name.
Files are transferred to the hard drive.



Click 'Next'.



Click 'Next' if you will not update the Program Folder name.



Files are transferred to the hard drive.



Click "Finish" to complete Setup.


Installing the Camera Driver for Windows 98/98SE/Me

Note: The graphics shown are based on the user interface in Windows 98.

1. Insert the CD-ROM into the CD-ROM drive
2. From the Windows Taskbar, click on **Start, Run**



3. Type the drive specification (d:\) of your CD-ROM drive and click **OK** button



4. Double-click on **Drivers** folder



5. Double-click on **setup.exe** file



6. Click **Next** button to start the camera driver installation



7. When Setup is complete, click **Finish** button to restart your computer



8. After your computer is restarted, power up your camera

9. Switch the **Mode** dial to **PC** mode

10. Connect the camera and computer with the USB cord

11. **Removable disk** will automatically be installed in your computer. Several screens will appear temporarily

12. When the Removable disk installation is complete, press **MENU**, **DOWN** and **ENTER** buttons on the camera to select **Silent Video** mode

13. The Video driver will be installed in your computer


14. The driver installation is complete

Note: In rare occasions the installed camera driver may possibly conflict other USB devices in your computer system.

Installing Arsoft PhotoImpression Application Software

Review your images

1. Make sure the camera is connected to your computer and is in **Mass Storage** mode. Press **MENU**, **UP**, **ENTER** buttons on the camera if necessary.
2. Open Windows Explorer
3. Search through **Removable Disk>100cnxnt** and double-click on the **100cnxnt** folder
4. The image files are shown in the right pane



Check the video driver

1. Press **MENU**, **DOWN** and **ENTER** buttons on the camera to select **Silent Video** mode
2. Search through **Start>Settings>Control Panel>System>Device Manager>Imaging Devices>DSC350**




USB Video Camera


Installing the camera driver for Windows XP/2000:

Note: The graphics shown are based on the user interface in Windows XP.

1. Insert the CD-ROM into the CD-ROM drive
2. Click on **Start>Run** at Windows Taskbar



3. Type the drive specification of your CD-ROM drive (d:\) and click **OK** button




4. Double-click on **Drivers** folder



9. After your computer is restarted, power up your camera
10. Switch the **Mode** dial to **PC** mode
11. Connect the camera and computer with the USB cord
12. **Removable disk** will automatically be installed in your computer. Several screens will appear momentarily.
13. When the "Removable Disk" installation is complete, press **MENU**, **DOWN** and **ENTER** buttons on the camera to select **Silent Video** mode
14. The Video driver will be installed in your computer
15. Click Next to install



16. Click **Continue Anyway** button (Win XP) or **Yes** button (Win 2000) when you see the warning message



17. Click **Finish** button to end



18. Drivers installation is complete

Note: In rare occasions the installed camera driver may possibly conflict other USB devices in your computer system.

Check your image files

1. Make sure the camera is connected to your computer and is in **Mass Storage** mode. Press **MENU, UP, ENTER** buttons on the camera if necessary.
2. Open Windows Explorer



3. Search through **Removable disk>Dcim>100cnxnt** and double-click on the **100cnxnt** folder
4. The image files are shown in the right pane




Check the video driver

1. Press **MENU, DOWN** and **ENTER** buttons on the camera to select **Silent Video** mode
2. Search through **Start>Control Panel>System>Hardware>Device Manager>Imaging devices>DSC350 USB Video Camera**



Using PhotoImpression (Wal-Mart version)



Open PhotoImpression :

1. Search through Start>Programs>Arcsoft PhotoImpression>Arcsoft PhotoImpression 3.0. You should get the screen on the left.



Create new album :

1. At the lower part of the screen, select [New] from the pull-down menu as shown. You can change the name of the new album to, say "My Photos".

Add images from your camera :

1. Take some images, turn the Mode dial to "PC", and connect the camera to your PC
2. Click the "Add" icon as shown
3. From the Open dialog box, select Removable Disk X: (where X is the next available drive specification in your computer)
4. Double-click on "Dcim" and then "100cnxnt" folder
5. Click on the images you wish to add and click Open. The added images will appear as small thumbnail images.



Note: Only thumbnails are saved to the album. If you want to access the images when the camera is disconnected, make sure you save the image files to your hard drive



Slide Show :

After creating the album, you can click the 'Slide Show' icon to play slide show of this album.

Using the TWAIN Driver to Acquire images:



1. Take some images, turn the Mode dial to "PC", and connect the camera to your computer
2. Click the Camera/Scanner icon
3. Select DSC 350 USB Still Camera from the "Select Source" pull-down menu
4. Select [New] from the "Select Album" pull-down menu
5. Click on "Acquire" icon to open the camera driver dialog panel
6. Select the images (or Select All)
7. Click Save icon to export the selected images to the folder Desktop\My Photos





Use the "Video Camera" function:

1. Connect the camera to your computer and switch the Mode dial to "PC" mode
2. Press MENU, DOWN, ENTER to set the camera to "Silent Video" mode
3. Click "Video Camera" icon
4. Select DSC350 USB Video Camera from the Drivers pull-down menu of the "Capture Image from Video Camera" dialog box
5. Click "Live" button
6. Click "Capture" button to take an image and save it to your selected album



Edit images:

1. Click Edit icon on the upper left hand corner
2. You will see the Edit menu on the lower left hand corner
 Select & Crop
 Retouch
 Text
 Enhance
 Effects
 Layers
3. Click the "?" (Help) icon on the top right hand corner for help



Create function

1. Click Create icon on the upper left hand corner
2. You will see the Create menu at the bottom
 Frames and Edges
 Cookie Cutter
 Calendar (up to year 2010)
 Greeting Cards
 Prints & Gifts (to Walmart.com)*
 Cool Software
3. Click "?" (Help) icon on the top right hand corner for help

* By selecting this function, you can access the Walmart photo center website by clicking the "Begin" icon. Make sure you have connected your computer to the Internet.



Save and Print

1. Click Save icon on the upper left hand corner
2. You have three selections:
 - To file: Save images to hard drive
 - Email: Send images by email
 - walmart.com: Upload images to the Walmart photo center

Print function:

1. Click Print icon on the upper left hand corner
2. You can print images in the following two ways:
 - Using your printer to print single/multiple images or thumbnails
 - Connecting to Walmart photo center websites for Order Print

Review the Camera User's Manual:

The User's Manual is provided in two versions:

1. User's Manual booklet and
2. Manual.pdf file in the CD-ROM

To open the Manual.pdf file in the CD-ROM:


1. Insert the supplied CD-ROM into the CD-ROM drive
2. Click Start>Run on Windows Taskbar
3. Specify the CD-ROM drive letter and click OK
4. Double-click the Manual.pdf icon to open the file

Acrobat Reader is also provided for you to open the Manual.pdf file. If it has not yet been installed in your computer, double-click the ar40eng.exe file on the CD-ROM and follow the installation instructions.

Uninstalling the Arcsoft Application Programs:

To uninstall Arcsoft PhotolImpression

1. Search through Start>Programs>Arcsoft PhotolImpression>Uninstall
2. Click on Uninstall button



Troubleshooting:

If you experience difficulty with your camera, check the following:

- | | |
|---|---|
| 1. No Power | The battery are depleted, or battery polarities are inverted (backwards) |
| 2. No Image is taken | Internal memory, or CF card, is full |
| 3. Flash does not operate | Camera set to flash off mode. Battery power is low. |
| 4. Image are too dark with flash | The subject is too far away. Flash was obscured. |
| 5. Image is blurred | The lens is dirty or has condensation |
| 6. Can't erase an photo | It is protected. Unprotect it. |
| 7. LCD monitor is off | The Mode Dial is set incorrectly |
| 8. No display on the status LCD | The camera has auto-powered off |
| 9. Card Full is displayed | No CF card is inserted, or the card is full |
| 10. The object is too dark | Change the position to avoid backlit problem. Use eV compensate. Try 1eV or 1.5eV. |
| 11. The object is unclear | Environment is too dark. Use flash or tripod. |
| 12. Images are too yellow | Change the White Balance to other settings. |
| 13. Camera does not recognize CF card | Power the camera off and on. Verify that the CF card is fully inserted. |
| 14. I cannot use the video camera mode | Make sure you have selected 'silent video' mode |
| 15. I am using "Easy-CD Creator (version 4.X or below) and I have problem installing the camera driver, what should I do? | <ul style="list-style-type: none">• DSC350 Digital Camera's installation CD includes an "auto-check" program to detect if your PC has any software conflicts between other devices and the camera. If the "auto-checker" detects existence of software conflicts, it will recommend and guide the user to download updated drivers from appropriate website to solve the conflict problem.• If you cannot download the driver try the following procedures:<ol style="list-style-type: none">1. Insert the DSC350 Digital Camera installation CD into the CD-ROM drive2. Look for the file "recover.bat" stored on the CD3. Double-click the file to initiate the recovering process4. Restart your computer5. Install the camera driver again |

PRODUCT SPECIFICATIONS

1. Resolution	FULL: 1280 x 1024 (SXGA), HALF: 640 x 480 (VGA)
2. Image Quality	*** FINE, ** NORMAL, * ECONOMY
3. Lens	Glass, 5 elements, F/2.8, 35mm(Equiv)
4. Number of Images (Built-in memory)	FULL *: 1 HALF*: about 6
5. 1.8-inch LCD monitor	280x220 dots, True color TFT display.
6. LCD monitor Menu	Seven languages (European and Japanese)
7. Special Features	Quick View, Slide show, Folder selection, Image Date/Time adjust, Auto power off time, Erase Current/All
8. Others	View Finder, Status LCD, Buzzer, LED, Tripod mount
9. Buttons and Switch	Ten control buttons and one rotary Mode Dial
10. Strobe Flash	Four modes: Auto, On, Off, Red-Eye.
11. Battery Power	Alkaline AA battery x 4 (6V)
12. Auto-Off	1, 2 or 3 minutes -- selectable
13. Self timer	10 second delay
14. TV video out	NTSC or PAL, selectable
15. White Balance	Auto, Daylight, Incandescent, Fluorescent1, or Fluorescent2
16. Digital Zoom	2X digital zoom. (HALF *)
17. File format	JPEG (DCF compatible)
18. Focusing range	1m to infinity (fixed-focus lens)
19. EV Compensation	From -1.5 to +1.5 EV, step 0.3 EV
20. Low Battery Detection	Two levels
21. Battery Life (Alkaline)	Approx. 1 hour with LCD monitor on
22. Operating conditions	0 ~ 40 degree Celsius
23. Dimensions	80 x 110 x 35 mm (HWD)
24. Net Weight	190g w/o battery

Software :

1. Camera Driver	USB Type, Removable Disk
2. Photo Impression	1. Print images in simple steps 2. Photo editing program 3. Link to walmart.com

Specifications are subject to change without notice.

System Requirements:

1. Pentium 300MHz or above.
2. Operating Systems: PC Win98/ 98SE/ 2000/Me/XP*
3. 32MB SDRAM minimum for Win98/98SE
64MB SDRAM for WinMe/Win2000
128MB for WinXP.
4. Minimum 300MB hard disk free capacity, 1GB for WinXP.
5. With USB port and CD-ROM drive.

* Camera driver installation on Windows XP is done at users' own risks. We accept no responsibility for any damage caused to users' computer systems or any other related equipment.

